




Date: October 1, 2007 **TN 823-1**

Subject: MEK Rub Test Machine
Models: All
Scope: Re-Packing Guideline

Instructions for packing MEK Rub Test Machine in ISPM15 compliant crate.

	<p>Place machine base as shown and set the MEK Rub test machine on top of base the machine feet should nest into the 4 holes in the base plate.</p>
	<p>Place blocking on the top of the MEK Rub Tester as shown and strap the block and machine to the base plate using banding as shown.</p> <p>Note: The rubbing head should be in the down position under the shipping block as shown.</p>
	<p>View of machine and blocking strapped to base.</p>



Set Machine into crate as shown, orientation of machine is important as the base plate hold down screws must be screwed through the crate base and into the crate footings.



Use 4 screws provided to secure assembly into the crate.

Failure to properly secure the machine to the base and to the crate structure may result in damage to the machine.



Band crate as shown; do not ship crate un-banded doing so may result in damage to crate and machine.