

Date: October 21, 2009

TN MEK102109

Subject: Cover Lock  
Models: Sn. 2176 and up  
Scope: New safety cover locking device

With the addition of the safety cover interlock on all new MEK Rub Test Machines we have now added a cover locking device that will keep the cover in the raised position allowing for easier and more convenient lowering of the rubbing head onto the sample.

The locking devices have either a pull ring or a small knob that is pulled back to release the spring plunger and allow the cover to be lowered. The locking device is installed on the left hand side cover mounting block. This option is only available on newer MEK Rub Test Machines that are equipped with the cover interlock device. The interlock prevents the machine from running with the cover in the raised position.



Cover locking device



Pull ring or if equipped the small knob back to release the cover.